



NEV-COMM

6170 West Lake Mead Blvd. PMB 299 Las Vegas, NV 89108 (702) 320-2800 Fax (702) 396-2845

Toshiba Strata CTX

Enter programming mode by pressing: Hold * # * # 1 * 2 * 3 *

Enter Password: 0000 Hold (Default password is 0000; that's four zeros)

At the "PROG=" prompt enter: 9 0 2 Hold

At the "SELECT PARAM" prompt press: Line Key 02

Enter time in 24 hour format: (HH/MM/SS)

(Where HH is two digits for Hours, MM is two digits for Minutes and SS is two digits for Seconds)

To change program, press: Hold

To submit changes, press: Hold

And to exit program mode, Enter: # # Hold